

Congratulations on the recent purchase of your new Sun Dolphin Paddleboard (SUP) manufactured by KL Outdoor! You have purchased a paddleboard from one of the nation's leading manufacturers of small boats. Your paddleboard represents years of commitment to product design, excellence in engineering and quality in manufacturing. With proper care and maintenance, your paddleboard should last for many years to come. If you have any questions, please call our helpful and knowledgeable Customer Support Department.

MATERIALS

Your paddleboard is manufactured from High Density Polyethylene (HDPE). It is a very durable material. Our specially formulated HDPE has an ultra-violet inhibitor blended throughout the material to reduce color fade and maintain its strength. Polyethylene is a somewhat flexible material with some memory. This means it has a tendency to return to its original molded shape if distorted.

BOAT SET-UP

Fin

To install, follow instructions included with fin kit.

Paddle

Attach the two pieces of your paddle together by pressing in the lock button and releasing into the desired hole location. Your paddle can be adjusted to three different lengths.

Drain Plug

Make sure drain plug is secure. The drain plug is located at the rear of the deck.

Paperwork

Warranty Registration Card

To properly register your boat with KL Outdoor for warranty validation please fill out the warranty registration form online at www.sundolphin.com. Please review our full warranty statement. The serial number can be found in the back right-hand corner of the paddleboard.

Manufacturers Statement of Origin (MSO)

You should receive a MSO with your new paddleboard. Some states may require a MSO for proper registration of your paddleboard. Please check with your local licensing bureau.

Owner's Manual

Keep your owner's manual f	or future reference. It is a good idea to write down the following information:
Serial Number	
Date of Purchase	
Purchased from	

Applying Decals

Before applying boat registration decals (if required), clean the area with alcohol or any solvent that does not leave a residue. Make sure solvent is put aside and is dry. Using a propane torch, lightly pass the flame back and forth over the area where the decals will be applied. **Don't try to heat the surface.** This process will enhance the adhesion of the decals.

TRANSPORTING YOUR PADDLEBOARD

Avoid direct sunlight when possible. If you must expose your paddleboard to direct sunlight during transport it is best to keep the bottom facing upward. Exposing dry deck pad to direct sunlight may cause damage.

Paddleboard bags are available at local retailers for protection during transportation. However, do not store your paddleboard in the bag for extended periods of time.

CARE AND MAINTENANCE

Your paddleboard is designed to require minimal maintenance and a little timely care will ensure a lifetime of enjoyment.

- Whenever you wash your paddleboard use mild soap and water. Rinse your paddleboard and hardware thoroughly with fresh water after paddling in salt, brackish or polluted water.
- Drain any water accumulated between the deck and hull. The drain plug is located at the rear of the deck.
- Use care when beaching your paddleboard to protect the fin. Avoid dragging across asphalt, concrete or sharp rocks to prevent excessive wear and abrasion to the hull.
- Occasional operational checkups will keep your paddleboard in tip-top condition. Give your hull and deck a thorough review annually. Light nicks, scratches and scrapes are part of the paddling experiences but deep scratches should be repaired.
- Never leave board exposed to direct sunlight when out of the water. Always keep in the shade when not in the water. If you must expose your paddleboard to direct sunlight during transport or temporary storage it is best to keep the bottom facing upward. Never leave deck pad facing the sun when dry. Exposing deck pad to direct sunlight may cause damage.
- Remove and store fin(s) after each use to prevent damage.
- To aid in opening and closing the deck plate, the manufacturer of the deck plate recommends cleaning the deck plate with hot soapy water and lubricating the threads with Teflon grease or Vaseline.

Overheating your paddleboard is not covered under manufacturers warranty.

STORAGE

- Store board in a dry, cool environment. Avoid direct sunlight. If possible it is best to store your paddleboard inside for the winter.
- Do not store your paddleboard in a board bag for extended periods of time. Board bags are intended for transportation
 protection. Storing your paddleboard in a board bag in direct sunlight is not the same as placing it in the shade. Board bags
 collect heat and may damage your paddleboard.
- · Do not store your paddleboard in a damp board bag.
- · Remove and store fins after each use.
- · Don't allow water to accumulate between the deck and hull and freeze.
- Don't place the paddleboard on 4x4's or sawhorses. Dents will form in the hull.

OPTIONAL ACCESSORIES

Order online at www.sundolphin.com.

FREQUENTLY ASKED QUESTIONS

- 1. Where is the serial number located? The serial number is located on the rear right-hand side of the deck. The number starts with JOK and is 12 digits long.
- 2. There is water inside my boat. Is this normal? Just like any boat, your boat may take on some water. Because of its flexible nature, a polyethylene boat is prone to accumulate a small amount of water between the deck and hull. Water may accumulate between the deck and hull due to rain, waves and condensation. This is normal, not a defect, and should be drained periodically. Do not return to the retailer. Remove the drain plug located at the rear of the deck and tip the boat up to drain. Replace the drain plug.
- 3. How should I store my boat in the winter? See Storage.

SECURITY MEASURES


⚠ WARNING

Read the following information before using your paddleboard. Failure to follow the warning precautions below may lead to serious injury including the possibility of death.

- A Never exceed your ability: Access your physical capability as to how long you can paddle and swim.
- ⚠ Make sure drain plug is secure. The drain plug is located on the rear deck.
- Always familiarize yourself with the body of water where you will be paddling: Learn what hours are permitted, whether there are any known hazardous conditions, and where you can get help quickly in case of an emergency or accident.
- A Never use or consume alcohol, drugs or any other substance that may affect your coordination, judgment or ability to safely operate the paddleboard.
- △ Slippery when wet: The hull material may be slippery when wet. Always wear slip-resistant shoes.
- △ **Hypothermia:** Hypothermia (the loss of body heat due to immersion in cold waters) can be deadly. Survival time can be as short as 15 minutes in 35 degree F (2 degree C) water. Dress appropriately for weather conditions, wearing a wet or dry suit if necessary.
- **⚠** Never allow minors to use this paddleboard without adult supervision.
- △ Always tell someone your paddling plans. Inform others of your paddling plans, including where you are going, how long you will be gone and when you expect to return.
- **△** Never use this paddleboard in severe weather conditions.
- ⚠ This paddleboard is designed for leisure. The paddleboard could be damaged and (or) the occupants could be severely injured should they attempt to utilize it in any other way.
- A Never use this paddleboard after sunset: This paddleboard is not equipped with horns or lighting equipment required to ensure the safety of its occupants.
- **△** Always wear a helmet where appropriate.
- Always wear a Coast Guard approved Personal Flotation Device (PFD) when using this paddleboard: Before going paddling, read the PFD manufacturer's information pamphlet regarding the PFD and thoroughly familiarize yourself with how the PFD is to be worn.

Please Choose Your Model

Ahala 10.5




Cm	soifi o	ations
SDE	CHIC	ations

Specifications				
Length	10'	305cm		
Width	33"	84cm		
Depth	10"	25cm		
Weight*	50 lbs.	23kg		
Capacity	230 lbs.	104kg		

Length	10½′	323cm
Width	34"	86cm
Height	6"	15cm
Weight	48 lbs.	22kg
Canacity	230 lbs	104kσ

Specifications





LIMITED LIFETIME WARRANTY

GENERAL INFORMATION

Your KL Outdoor product represents years of commitment to product design, excellence in engineering and quality in manufacturing. With proper care and maintenance, your KL Outdoor product should last for many years to come. If you have any questions or need technical support, please go to the "Contact Us" section of our website at www.kloutdoor.com or contact our Customer Service Department at 800-733-2727.

Do not return your KL Outdoor Product to the retailer. If you have any questions regarding a product, please first contact us. In order to provide you with efficient and accurate service, please have the following information available: model and serial number, date and proof of purchase.

PLEASE, ALWAYS REMEMBER TO WEAR A PROPER PERSONAL FLOATATION DEVICE WHEN USING OUR BOAT PRODUCTS. ALWAYS CHECK WEATHER CONDITIONS, OBSERVE ALL COAST GUARD SMALL CRAFT WARNINGS. AND PROPERLY SUPERVISE CHILDREN USING BOAT PRODUCTS.

HOW TO REGISTER YOUR BOAT

This Limited Lifetime Warranty is not valid unless registration is submitted within 30 days of retail purchase. Please register your Product via our website at www.kloutdoor.com.

TERMS OF LIMITED LIFETIME WARRANTY

KL Outdoor's Limited Warranty is subject to the Exclusions and Limitations set forth below and is valid only if the product i) is properly cared for and maintained, in accordance with the applicable user manual, and ii) is used for the intended purpose for which it was designed.

KL Outdoor warrants to the original owner of any KL Outdoor product purchased from an authorized dealer or retail outlet, for the period set forth below with respect to the applicable product ("Product Warranty Term"), against any defects in workmanship. Products with valid claims for such defects will be repaired or replaced, without charge, at the purchasers' local authorized dealer or at KL Outdoor. This warranty is non-transferable.

PRODUCT WARRANTY TERM*

Boat Deck and Hull: Limited Lifetime to the original owner only; Boat components: one (1) year; Terrain Sleds: two (2) years; Terrain Hunting Blinds: one (1) year *Subject to Exclusion and Limitations below. Product Warranty Term is measured from date of purchase.

EXCLUSIONS AND LIMITATIONS

This warranty does not cover:

- 1. Damage caused by accidents, vandalism, abuse, misuse, neglect or carelessness.
- 2. Any defect cause by alteration or modification.
- Any product used for rental or commercial purposes.
- 4. Damage caused by Mother Nature, environmental conditions or other causes beyond the control of KL Outdoor, including without limit sun-exposure fade.
- Deterioration from normal wear or exposure.
- Any defect which would not have occurred if instructions in the owner's manual had been properly followed.
- 7. Abrasion damages to the deck or hull of any boat product or other products.
- 8. Damages incurred in possession of a freight company or any other third party.
- 9. Loss of electronic devices. We do not have any water proof compartments in our boats and caution should be taken when bringing any electronic devices in any boat product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY AND ALL OTHER WARRANTIES, INCLUDING WITHOUT LIMIT ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR OTHER WARRANTY OF QUALITY, WHETHER OR NOT EXPRESS OR IMPLIED.

CLAIMS PROCEDURE

The return of any KL Outdoor product subject to a valid Limited Warranty claim will not be accepted without a return authorization number. The retailer can obtain this number by contacting our Customer Service Department.

Any claim under this Limited Warranty must be communicated via our website at www.kloutdoor.com or by contacting Customer Service. Please have the following information available: model, serial number, proof of purchase and photos of the defect. KL Outdoor will evaluate the information and determine if it is a valid defect in workmanship prior to issuing a return authorization number. KL Outdoor reserves the right to discontinue and make changes in any of its products. In the event that products covered by this Limited Warranty are not available, KL Outdoor shall have the right to substitute products at KL Outdoor's sole discretion of comparable grade, quality or price.

Waiver of one or more claims procedures shall not act to void or waive any other term of this Limited Warranty or any future occurrence of the provision waived.

Freight to and from your local dealer, retailer or KL Outdoor is at the owner's expense. KL Outdoor is not responsible for any damages incurred in transport, for storing or for inconvenience or loss of time or money while repairs or replacements are being made.

LIMITATION OF LIABILITY

ALL INCIDENTAL, SPECIAL, AND/OR CONSEQUENTIAL DAMAGES are excluded from this Limited Warranty. Implied warranties, to the extent prohibited from exclusion hereunder by a specific State law, are limited to the Product Warranty Term of this Limited Warranty in such State jurisdictions. To the extent a specific State does not allow i) limitations on how long an implied warranty lasts, or iii) the exclusion or limitation of incidental or consequential damages, then the above limitations or exclusions may not apply to you provided you are otherwise subject to such State jurisdiction. This Limited Warranty gives you special legal rights and you may also have other legal rights which may vary from state to State to the extent not limited hereunder.

This Limited Warranty only covers products within the continental United States, Canada and Mexico. No warranty is offered on any KL Outdoor Product sold in any other country.